

Waterproofing Cables Using Fusion Tape

1. Securely connect the cables.



2. Peel plastic liner off Butyl Rubber Fusion Tape.



3. Apply adhesive side of fusion tape to cable surface. Wrap tape in a spiral, stretching enough to create a tension that conforms to the cables. Overlap each turn roughly 50% until the connection is completely encased in tape.

